

Assembly Instructions DCF 600


Short information.

The DCF Modules are new and came with wires prefabricated
I desoldered these to use it for this projects

Assembling order

- Resistors
- Diode
- Transistor
- Capacitors
- Pin Headers
- 5 pin Header. Please Pin 2 und 4 take out before soldering
- DCF Modul
- Ferrite
- with Glue pad and Strip

- + red
- ┌ green
- black



DCF Case 65mm x 46mm x 26mm

After power connection and 2 - 10 seconds the LED in DCF Module flashes.

After synchronisation with DCF Signal flashing will be each second .

If not please turn the Module in direction to Frankfurt, Germany.

Time, Date and Weekday appears after 2 - 6 Minutes.

